

- Punch or drill properly sized mounting hole in sheet. Do not perform any secondary operations such as deburring.
- Place shank of nut into mounting hole, preferably the punch side.
- With punch and anvil surfaces parallel, apply squeezing force until the flange contacts the mounting sheet. The sketch below indicates suggested tooling for applying these forces.

